

Recap of the terminology

Steady: $\underline{q} = \underline{q}(\underline{r})$, i.e. no time dependence

Two-dimensional: $\underline{q} = u(x, y)\underline{i} + v(x, y)\underline{j}$.

Incompressibility: $\nabla \cdot \underline{q} = 0$.

Stream function ψ : $\underline{q} = (\nabla\psi) \times \underline{k}$.

Stagnation points: $\underline{q}(\underline{r}) = \underline{0}$.

Vorticity: $\underline{\omega} = \nabla \times \underline{q}$.

Irrotational flow: $\underline{\omega} = \underline{0}$.

With irrotational flow there exists a velocity potential ϕ such that

$$\underline{q} = \nabla\phi = (\nabla\psi) \times \underline{k}.$$

with

$$\nabla^2\psi = \nabla^2\phi = 0.$$

The velocity in Cartesian and polars coordinates

In Cartesian's $\psi = \psi(x, y)$ and

$$\underline{q} = \frac{\partial\psi}{\partial y}\underline{i} - \frac{\partial\psi}{\partial x}\underline{j}$$


and in polars $\psi = \psi(r, \theta)$ and

$$\underline{q} = \frac{1}{r} \frac{\partial\psi}{\partial\theta} \underline{e}_r - \frac{\partial\psi}{\partial r} \underline{e}_\theta.$$

Curves of the form $\psi = \text{const}$ are the streamlines of the flow.


Streamlines for a simple shear flow

$$\psi = \frac{1}{2}\beta y^2 \quad \text{and} \quad \underline{q} = \beta y \underline{i}.$$




Streamlines for a line source at $r = 0$

$$\psi = A\theta \quad \text{and} \quad \underline{q} = \frac{A}{r} \underline{e}_r.$$



Streamlines for a line vortex at $r = 0$


$$\psi(r) = -\frac{\Gamma}{2\pi} \ln\left(\frac{r}{a}\right) \quad \text{and} \quad \underline{q} = \left(\frac{\Gamma}{2\pi}\right) \frac{1}{r} \underline{e}_\theta.$$




A source and sink close together

If $Ah = \mu$ is constant and $h \rightarrow 0$ then we can show that

$$\psi(\underline{r}) = Ah \frac{(\theta_1 - \theta_2)}{h} \rightarrow \mu \frac{\sin \theta}{r}.$$




Streamlines for a dipole in the i direction



Streamlines for a dipole in the $-i$ direction


$$\psi = -\mu \frac{\sin \theta}{r}$$



This is the same as before with the arrows reversed.


Streamlines for uniform flow in the i direction

$$\psi = Ur \sin \theta$$




Streamlines for flow round a cylinder

$$\psi = U \left(r - \frac{a^2}{r} \right) \sin \theta$$



Flow around a cylinder – Reynold's number, $Re=1$

When we have some viscosity we get a similar pattern.



Flow around a cylinder – $Re=10$

When the viscous effects increase flow differs from the no viscosity case close to the cylinder.

